

Easy To Use!

Easy To Clean!

1. FILL THE BULB WITH WATER

by submerging the Grit-Gitter with the bulb end down. Squeeze the bulb one or two times to help remove the air.

2. AIM & SQUEEZE

in one smooth easy motion, squeeze the bulb, and releasing the bulb quickly, move the Grit-Gitter forward (3 to 6 inches) over the grit. A momentary delay before squeezing again works best.

3. CLEAN

Not only does the Grit-Gitter make cleaning easy, it cleans easily too. Just empty the contents outside your tub and rinse the screen. Clean frequently, or whenever squeezing the bulb squirts grit and water out of the nozzle.

To empty the debris, rotate the bulb counter-clockwise 15" and pull the bulb/ring straight away from the body. Dump the contents outside the tub. Fill the bulb with water and pour over the screen to rinse all the debris off the screen. Be sure no debris remains in the connection area so that there is no interference when you reassemble the bulb to the body. To reassemble, line up the red mark on the body and the red dot on the ring. Push the bulb into the body and rotate the bulb clockwise 15" until the ring locks in place.

