



|                                 |     |     |     |     |     |     |
|---------------------------------|-----|-----|-----|-----|-----|-----|
| <b>Alk</b><br>alkalinity<br>ppm | 0   | 40  | 80  | 120 | 180 | 240 |
|                                 | OK  |     |     |     |     |     |
| <b>pH</b>                       | 6.2 | 6.8 | 7.2 | 7.6 | 8.0 | 8.4 |
|                                 | OK  |     |     |     |     |     |
| <b>Cop</b><br>copper<br>ppm     | 0   | 0.3 | 0.6 | 1.0 | 3.0 |     |

Immerse strip.  
**SWIRL 3 XS**.  
Remove with  
**pads face up.**  
**DO NOT SHAKE**  
**OFF EXCESS**  
**WATER.** Wait 10  
seconds for  
alkalinity color to  
develop then read  
result:  
Alk → pH → Copper  
\*In cup-size samples,  
swirl 5 times.

- Keep wet fingers out of the bottle. Close vial lightly. Store in cool, dry place.
- In pools, immerse strip to a depth of 12"-18" and read in natural light.
- In spas, turn off jets and immerse strip to a depth of 6".



Christietown, MD 21620 USA  
www.lamotte.com/insta  
Code 3001-G  
made in USA

