

Insta-TEST[®]

10 Test Strips
10 Tiras de Análisis
10 Bandelettes d'Analyse

Sodium Bromide

Bromuro de Sodio

Bromure de Sodium



LaMotte

SODIUM BROMIDE ppm



Dip pad into sample and immerse for 7 seconds. Remove strip with pad face up. **DO NOT SHAKE OFF EXCESS LIQUID.** In 30 seconds, hold pad level. **20 seconds** after removing strip. Discard strip after 30 seconds.

- Keep out of direct sunlight during testing.
- Keep wet fingers out of the bottle.
- Close vial tightly after removing strip.
- Store indoors in a cool, dry, dark place.

Immersion pour 2 secondes dans l'échantillon et retirez la bandelette avec le NE PAS SECOURIR. À l'ombre, gardez le niveau de la bande pour **20 secondes** et lire. Jeter la bande après 30 secondes.

- Garder hors du soleil durant l'analyse.
- Éviter les doigts humides sur les doigts trempés dans la bouteille.
- Refermer le capuchon.
- Entreposer dans un endroit frais, sec et ombragé.



Sumergir la tira en la muestra durante 2 segundos. Retírela con el lado coloreado hacia arriba. **NO SACUDA EL EXCESO DE AGUA.** Mantenga la tira horizontal a la muestra por **20 segundos** y haga la lectura. Descarte la tira después de 30 segundos.

- No exponga la tira al sol durante la prueba.
- No toque el envase con las manos.
- Cierre bien el envase luego de sacar la tira.
- Guarde el envase en un lugar frío, seco y oscuro.

Code 3036



LaMotte Co., Chestertown, MD 21620 USA
www.lamotte.com/insta