



Wide Range pH

Using a cup-size sample, immerse strip for **2 seconds**. Remove strip with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER**. With pad still facing up, wait **15 seconds** and **read** the strip. Discard strip after 30 seconds.

TIPS

- Keep wet fingers out of the bottle.
- Cap bottle tightly.
- Store in a cool, dry place.

LaMotte Made in USA

Chestertown, MD 21620
www.lamotte.com

Code 2974

6 37395143131 9

Lot#255621 Exp. 11/06